

1- VALVES CODIFICATION

VCR® fittings modularity :

- 2 ways : according to chart # 1
- 3 ways : according to chart # 3
- 4 ways : according to chart # 5

Inlet/Outlet :configuration of ways :

- 2 ways : according to chart # 2
- 3 ways : according to chart # 4
- 4 ways : according to chart # 6

Position of the pneumatic actuator at rest :


- NO : Normally Open
- NF : Normally Closed

Multi-actuators : contact Flowlink

CHART # 1 (for "EL" Elbow valves ONLY)

	1	2
MO 1	F	M
MO 3	F	F
MO 5	M	M
MO 7	M	F

CHART # 2




C 1	
C 2	
C 6	

CHART # 3

	1	2	3
MO 1	F	M	F
MO 2	F	M	M
MO 3	F	F	F
MO 4	F	F	M
MO 5	M	M	F
MO 6	M	M	M
MO 7	M	F	F
MO 8	M	F	M

CHART # 4



- Way under stem tip
- Way in the chamber

C 1		C 4	
C 2		C 5	
C 3		C 6	

Example : VM 314 MO2 C4

